172-032-925 Issue G 26/08/2013 Sheet 1 of 3



Order Number

Serial Number

# PRODUCT/TEST MANUAL

### 3A32K25

## ITR INTERTRIP SEND AND RECEIVE RELAY

lssue Level	Date	Summary of changes
В	04/02/1998	Initial issue.
С	9/09/2002	TFA was 168948
D	10/04/2006	Added timing description to receive element
E	28/04/2006	Removed 5kV Impulse and replaced it with 1000Volt Megger test
F	20/01/2009	Update for TFA issue D
G	26/08/2013	Update for TfA issue E

Due to RMS continuous product improvement policy this information is subject to change without notice. This document is uncontrolled and subject to copyright.

Author	Checked & Registered	.pdf file created	Released
ERL	DG	DG	

172-032-925 Issue G 26/08/2013 Sheet 2 of 3



#### 1. ASSOCIATED DRAWINGS

172-032-125	Wiring Diagram
TfA 062240	Issue E 08/09/09

#### 2. INSULATION RESISTANCE CHECK

Check the insulation resistance at 500VDC for the following cases in Table 1. Note that the resistance shall be <u>no less than  $100M\Omega$ </u>.

Table 1				
Terminals A	Terminals B			
5	1&3, 10&12 , 17&19			
1&3	5, 10&12 , 17&19			
10&12,	5, 1&3, 17&19			
17&19	5, 10&12 , 17&19			
All	Earth			

#### 3. HIGH VOLTAGE TESTING

Apply 2kV RMS 50Hz between terminals as in Table 1 above for 1 minute.

Apply three 5kV 1/50us pulses of each polarity between terminals as in Table 1 above.

#### 3. TEST PROCEDURE

#### 3.1 SEND ELEMENT (S)

- a) Check coil resistance is  $200 \Omega + 10\%$ .
- b) Check that relay **operates at < 8V DC and > 5V DC**

Ω

V

- c) Energise the SEND coil by applying 20VDC between terminal 1 (+) and 3 (-).
- d) Check that the time for the armature operated contacts to close by <u>measuring across</u> terminals: <u>5 &19 (20R)</u>, <u>3 & 17 (20R)</u> and <u>1&5 (0R)</u> is as follows:

#### Timing > 140ms at 20 V DC

Check that the coil power on 1& 3 is de-energised by its coil series flag operated contact .

ms

172-032-925 Issue G 26/08/2013 Sheet 3 of 3

4.



### 3.2 RECEIVE ELEMENT (R)

a)	Check coil resistance is 200 Ω +/- 10%.					
		Ω				
b)	Check that relay operates at < 8V DC and > 5V DC					
		V				
c) d)	Energise the RECEIVE coil by applying 20VDC between terminal 19 (+) and 17 (-). Check that the time for the armature operated contacts to close by <b>measuring across terminals: 12&amp;10 (0R), and <u>3 &amp; 17 (20R)</u></b> is as follows:					
	Timing < 70ms at 20 V DC					
	Check that the coil power on 1& 3 is de-energised by its coil series flag operated contact .					
		ms				
d)	Apply AC withstand of <u>85 - 90 VAC 50Hz</u> to the receive element. Ensure element does not pick up under 85VAC <u>when the voltage to the coil is increas</u> <u>slowly.</u>					
		ОК				
GENERAL & FUNCTIONAL						
a)	Check that relay nameplate is engraved					
	INTERTRIP RELAY RECEIVE SEND					
	and that the relay base is engraved with "ITR" and the stockcode number 62240.					
b)	Check that relay is shockproof and that the flag resetting mechanism operates correctly.					
c)	Check that the relay is electrically sound and mechanically robust as per Standard Inspection & Test Schedule 903-000-026.					
	PASS					
	TESTED BY: DATE	:				